






This radio is uniquely designed to provide a voice response for every action performed.

Setup

Extend the FM antenna found on the rear of the HD Radio. Connect the AM Loop Antenna to the AM Loop antenna input on the back of the radio. Plug in to outlet.

Once the radio is connected to the outlet it will announce “**Please Set The Clock**” (Refer to page 12 of the manual for clock setting instruction.)

	<p style="text-align: center;"><u>Power On/Off</u></p> <p>Press the Power button. Radio will start up in 2 seconds. Current station information will be announced. Press the Power button again to turn the radio off. If the alarm is set, an announcement of the time of the alarm will be heard.</p>
	<p style="text-align: center;"><u>Selecting Operation Mode</u></p> <p>Press the Mode button repeatedly to cycle thru AM, FM, and AUX modes. Press and hold the Mode button to set the time.</p>
	<p style="text-align: center;"><u>Tuning and Seeking AM or FM Stations</u></p> <p>Turn knob one click to tune, or rotate the knob several clicks to initiate ‘Seeking mode’. Press and release knob to hear current frequency.</p>
	<p style="text-align: center;"><u>Preset Memory</u></p> <p>Press and hold one of the Preset buttons for 2 seconds to save the current station to preset memory. To recall, just press and release one of the preset buttons.</p>
	<p style="text-align: center;"><u>Radio ID for Radio Reading Service</u></p> <p>Press and hold the RRS button to display and announce Radio Identification number needed to activate Digital Radio Reading Service.</p>